

NOOK HUDDLE POD



NOOK SOLO



NOOK SHELTER



MATERIALS

NOOK CONSISTS OF TWO PRIMARY MATERIALS.


- **A HARD PANEL** FOR THE OUTER SHELL, AND FOR THE FURNITURE (BENCHES, TABLE, WALLS AND, WHERE APPLICABLE, DOORS)
- **A FABRIC COVERING** UPHOLSTERY FOR THE CUSHIONS ON THE BENCHES, WALLS AND CEILINGS.

THE HARD PANELS ON THE SHELL AND FURNITURE ARE COVERED IN A HIGH PRESSURE MELAMINE LAMINATE.

THE FABRIC ON THE UPHOLSTERY, UNLESS OTHERWISE REQUESTED, IS RECYCLED POLYESTER.

MORE DETAILED CLEANING GUIDES FOR EACH CAN BE FOUND IN THE BELOW LINKS TO THEIR RESPECTIVE MANUFACTURER WEBSITES.

THE NOOK SOLO ALSO CONTAINS ACRYLIC FOR THE WINDOWS AND A PET ACOUSTIC BOARD ON ONE WALL AND THE CEILING.



HARD PANELS WITH MELAMINE LAMINATE FACE

[EGGER EURODEKOR CLEANING GUIDE](#)



FABRIC COVERING ON FOAM CUSHIONS

[CAMIRA FABRIC CLEANING GUIDE](#)

HARD PANELS (SHELL & FURNITURE)

Due to their resistant and hygienic surfaces, NOOK melamine-faced boards do not require any special maintenance. The surface is generally easy to clean; this also applies to textured surfaces.

The recommended cleaning methods according to the degree of soiling are as follows:

LIGHT, FRESH SOILING

Clean with a paper towel, a soft clean cloth (dry/damp) or a sponge. If using a damp cloth, dry the surface with an absorbent paper towel or microfibre cloth.

HOW TO AVOID STREAKS

Streaks often form when the surface is cleaned with organic solvents, together with cold water and old cloths. To ensure no streaks occur when cleaning, we recommend wiping the surface down with warm water and then drying it using normal paper towels or microfibre cloths.

CARE AND USAGE TIPS FOR MATT SURFACES

Surfaces with a matt finish have a very natural look and feel. The oiled or matt lacquered type finish thus retains the characteristics of the original, solid wood surface. Like high-gloss or solid wood surfaces, a few points need to be considered when using and caring for matt surfaces. As with other synthetic surfaces, normal soiling is easy to remove. What is important is that the surfaces are only cleaned with a soft, moist cloth. Under no circumstances must abrasive agents/powder, steel wool, polish, washing powder, furniture cleaner, bleach, acidic cleaning agents or steam cleaning equipment be used.

The reason for these precautions is that abrasive cleaners, rough cloths or scouring pads will cause bright patches or highlights in the surface if applied too vigorously, which damage the surface and are impossible to remove. Remnants of fat should also be removed as quickly as possible (within 48 hours) as the surface may be damaged if they are allowed to remain in contact with it for too long.

NORMAL SOILING – EXTENDED CONTACT TIME

Clean with warm water, a clean rag or microfibre cloth, a soft sponge or soft brush. Use normal domestic cleaners or soaps that have no abrasive ingredients. Then wipe with fresh water, removing all traces of the cleaning agent, to prevent streaks forming. Dry the surface with a clean, absorbent cloth or paper towels.

The following cleaning agents should not be used under any circumstances:

- Scouring and abrasive agents (abrasive powders, scouring pads, steel wool)
- Polish, washing powder, furniture cleaner, bleach
- Detergents with strong acids and acidic salts
- Steam cleaning equipment

FABRIC COVERINGS

FABRICS ARE USED IN NOOK IN TWO WAYS – REMOVABLE AND NON-REMOVABLE.

NOOK BENCHES ARE MADE WITH REMOVABLE FABRIC COVERS WITH ZIPS.

THE FABRIC ON NOOK WALLS AND CEILING CUSHIONS ARE NON-REMOVABLE.

KEEP THIS IN MIND WHEN READING THE FOLLOWING CLEANING GUIDE.

CONTRACT FABRICS DON'T LOOK AFTER THEMSELVES, EVEN THOSE WITH ADDITIONAL STAIN REPELLENT TREATMENT.

WITHOUT PROPER CARE AND ATTENTION THEY CAN LOOK OLD AND DIRTY WELL BEFORE THEIR TIME. IN EXTREME CASES THEY CAN EVEN WEAR THROUGH.

FOLLOWING A FEW SIMPLE RULES CAN ADD YEARS TO THE WEAR LIFE AND APPEARANCE OF WHAT SHOULD BE THE MOST VISUALLY APPEALING ELEMENT OF FURNITURE.

As easy as A, B, C

Use this simple guide to determine how specific stains should be treated.

Try step A first, applying small quantities of liquid and blotting well with clean tissues after each application. Work carefully to remove the stain from the outside in and allow to dry. If the stain is still apparent, try step B and later C.

Stain	A	B	C
Alcoholic drinks	9	11	7
Blood	5, 8	3	7
Butter	14, 15	1,2	3
Chewing gum	14	2,4	16
Chocolate	3	1	
Coffee	13	11	3
Cola/soft drinks	9	7	
Fruit juice	7	3	6, 3
Furniture polish	1	3	2
Gravy/sauce	3	1	7
Ink (biro)	6	4	10
Ink (felt tip pen)	6	4	3
Ink (writing)	3	16	
Jam	3	7	
Lipstick	1	2	3
Milk	8	3	7
Nail Varnish	4	16	
Oil & grease	1	2	3
Paint (oil based)	1	3	16
Paint (water based)	5	3	16
Shoe polish	1	2	3
Tea	3	11	7
Urine	3	12	16
Vomit	3	12	16
Wine	3	13	11

Key of treatments

1. White spirit, Turpentine or substitute
2. Dry cleaning fluid (1,1,1, Perchloroethylene)
3. Upholstery detergent or shampoo at manufacturer's recommended dilution
4. Acetone, nail polish remover – non oily
5. Cold water
6. Surgical spirit (alcohol)
7. Borax 2% solution, dissolve 1 teaspoonful in warm water, top up cup with cold water
8. Salt 2% solution, 1 level teaspoon in a cup of tepid water
9. Use 3 as above plus a drop of spirit vinegar
10. Biological detergent 1% solution (1 level tsp in cup of warm water)
11. Use 6 as above diluted with 1:5 water
12. Disinfectant, dilute as recommended on bottle, or 1 tsp in 2 pints of water
13. Use 7 as above plus a drop of spirit vinegar
14. Chill with ice cubes in a plastic bag
15. Hot iron over layers of white tissue
16. Consult a professional cleaner

TOP TIPS

Vacuum your fabrics regularly to prevent build up of dust and dirt on the fabric surface.

Get to spills and stains quickly. Mop up the excess liquid using kitchen roll or a damp cloth. Then clean using upholstery shampoo, detergent or handwash.

Always use a branded upholstery shampoo. Alternatively, default Nook fabric (polyester) can be dry cleaned.

Alternatively, choose a wipe down upholstery solution.

Nook bench cushions in the default Polyester can also be machine washed at 40°C - 60°C

PROVISIONAL NOTE:

This technical datasheet contains information added carefully and under precise investigation. Technical details are subject to change. The continuous development of products might result in differences, as well as renewals of standards and documents of public law. Therefore, NOOK can give no guarantee for misprint, or mistakes. This technical datasheet is not an instruction of use and not a legally binding document.